



## VX 11.1 - Test tube insert

Attachment for Eppendorf tubes or test tubes

Bore holes (number): 70

Hole Ø: 10 mm